


PARTS LIST

| ITEM | PART | DESCRIPTION | QTY |
|------|-----------|-----------------------------|-----|
| 1 | ZD-1006 | Wall Channels* | 2 |
| 2 | ZV-935 | Wall Anchors* | 6 |
| 3 | #8X1-1/4" | #8x 1-1/4" Screws* | 6 |
| 4 | #6X3/8" | #6 x 3/8" Screws | 10 |
| 5 | ZSS-3101 | Headers | 2 |
| 6 | ZSS-3101 | Curbs | 2 |
| 7 | ZV-902 | Glass Support Blocks | 2 |
| 8 | | Inline Glass Panel | 1 |
| 9 | ZV-909 | Vertical Seal Vinyl | 4 |
| 10 | ZV-906 | Horizontal Seal Vinyl | 4 |
| 11 | ZSS-1104 | 90° Posts | 1 |
| 12 | ZSS-1102 | Header and Curb Fillers | 2 |
| 13 | ZC90ADJ | 90 Degree Header/Curb Clips | 4 |



*NOTE: Items 1, 2 and 3 come with door stall wrap.


When ordering repair parts, please provide the following information:

1. Model Number
2. Part Number
3. Part Description
4. Finish Color

Required Tools:

To install your shower enclosure, you will need the following:

- Level
- #31 Drill Bit
- 3/16" Carbide Drill Bit (for tile walls)
- Phillips Screwdriver
- Silicone
- Hack Saw



INSTRUCTIONS:

Note: Wall channels (1), wall anchors (2) and screws (3) that are used in stall shower installation, are shipped with the shower door. Read both door and stall instructions before starting installation.

1. Add 1/2" to centerline measurement and cut curb to length.
2. Assemble curb with clips provided (Figure 1). Using template provided, drill holes for the corner clip by laying template on header or curb with the tab to the inside of miter. Using holes provided in header and curb, secure using eight #6 x 3/8" SMS Screws (4). Set curb in place and mark location on curb leaving curb in place temporarily.
3. Set wall channels into curb and mark holes on wall. Remove wall channel and drill holes into wall using 3/16" drill. Place plastic screw anchors into holes.
4. Run a 1/4" bead of silicone on underside of curb, inside miter and where the ends of the curb are on the threshold.
5. Replace curb and silicone where miters are, and where curb meets wall. Replace the wall channels and secure using #8 x 1 1/4" SMS.
6. Place glass support blocks in curb and set 90-degree panel in place, tacking at top with about 6" of the vertical seal vinyl. To adjust for wall conditions, adjust the panel in or out of the post, making sure that at least 1/4" remains in each channel.
7. Place corner post in place on other edge of glass and tack in place using vertical seal vinyl.
8. Check the chart for the door size, and obtain the range for the curb filler. If the distance between the wall channel and the corner post falls within this range then cut curb filler to size. If the measurement does not fall into the range, then a larger or smaller door is needed. Cut curb filler to size and snap in place with higher lip to outside of unit.
9. Snip excess vinyl from latch jamb, and crimp in place at top and bottom. Holding corner post, slip latch jamb into place.
10. Install 3" vinyl channel, centered on edge of glass and tap handle into place.
11. Set door (with hinge jamb attached) over wall channel. Door with hinge clip should be resting on curb filler.
12. Move the corner post and latch jamb in or out at the top of stationary panel until they align themselves with the glass.
13. **DO NOT MOVE FROM THE POSITION OF THE STATIONARY PANEL GLASS IN STEP #12**, because that determines the measurement of the header over the panel. Plumb the corner post to the door wall and measure from the corner post to the wall over the door. This determines the measurement of the header over the door. Add 1/4" to each of these measurements and cut the header and assemble. Place header in place and recheck alignment. If the alignment is good secure to wall channels and corner post. Snap header filler in place with lip to outside of unit.
14. Complete the installation of the vertical and horizontal seal vinyl.
15. Recheck alignment. If anything has moved, tape post to adjust. Adjust latch jamb for good fit. Use a #31 drill and #6 x 3/8 SM to secure to latch post.
16. Adjust splash vinyl so that approximately 1/8" daylight space remains between bottom of splash vinyl and curb filler




FIGURE 1

- 17. Install magnet catch on latch jamb.
- 18. Seal along inside and outside edge of metal and tile with silicone.

Header & Curb Fillers

| Header & Curb Fillers | | |
|---------------------------------|---------|---------|
| Min Filler = Door Size - 1 7/8" | | |
| Max Filler = Door Size - 1 7/8" | | |
| CD-20 | 18 1/8" | 19 1/8" |
| CD-21 | 19 1/8" | 20 1/8" |
| CD-22 | 20 1/8" | 21 1/8" |
| CD-23 | 21 1/8" | 22 1/8" |
| CD-24 | 22 1/8" | 23 1/8" |
| CD-25 | 23 1/8" | 24 1/8" |
| CD-26 | 24 1/8" | 25 1/8" |
| CD-27 | 25 1/8" | 26 1/8" |
| CD-28 | 26 1/8" | 27 1/8" |
| CD-29 | 27 1/8" | 28 1/8" |
| CD-30 | 28 1/8" | 29 1/8" |
| CD-31 | 29 1/8" | 30 1/8" |
| CD-32 | 30 1/8" | 31 1/8" |
| CD-33 | 31 1/8" | 32 1/8" |
| CD-34 | 32 1/8" | 33 1/8" |
| CD-35 | 33 1/8" | 34 1/8" |
| CD-36 | 34 1/8" | 35 1/8" |




FIGURE 2

FRAMELESS ENCLOSURES:

Model CD 90 36 Stall Shower - 90 Degree Panel & Door

BREAKDOWN CHART FOR SPECIAL HEIGHT AND WIDTH CD 90 36 UNITS:

| QTY. | Part# & Description | How to arrive at measurement |
|-------------|--------------------------------|-------------------------------------|
| 1 | ZSS-3101 Header | Unit width both sides |
| 1 | ZSS-3101 Curb | Unit width both sides |
| 2 | ZSS-1102 Filler | |
| 1 | ZSS-1103 180 Degree Post | Unit width minus 1-1/4" |
| 2 | *ZD-1006 Wall Channel | Unit height minus 1-1/4"* |
| 1 | *ZD-1004 Latch Jamb | Unit minus 2-3/8"* |
| 1 | *ZD-2505 Hinge Jamb | Unit height 2-3/8"* |
| 1 | *ZD-2503 Hinge Rail | Unit height 3-1/4"* |
| 1 | *ZD-1002 Bottom Rail | Door glass width minus 11/16"* |
| 1 | *ZD-1008 Drip Trough | Door glass width minus 3/16"* |

(see chart for door glass width)
 *These parts are from a CD

| Glass | | |
|--------------|--------|---------------------------------------|
| 1 | Width | Unit width minus door width, minus 1" |
| | Height | Unit height minus 1" |