

PARTS LIST

ITEM	PART	DESCRIPTION	QTY
1	ZTE-1203	Wall jambs	2
2	ZV-935	Wall Anchors	6
3	#8X 1-1/4"	#8x 1-1/4" Screws	6
4	ZV-924	Door Bumpers	2
4A	ZV-926	Bottom Bumpers	1
5	6-32 X 1/2"	6-32 x 1/2" Screws	2
6	ZTE-1222	Bottom Still	1
7	ZV-920	Center Guide - 3"	1
8	ZTE-5201	Header	1
9	CHG-TB	Tubular Towel Bar	1
10	CHG-KSM	Tubular Inside Pull	1
11	ZTE-2205	Towel Bars/Pull Fastener	3
12	CAP34	Nylon Towel Bar Washer	6
13	1/4" Nylon Sleeve	Nylon Towel Bar Sleeve	3
14	#6X3/8	#6 x 3/8" Screws	2
15	ZTE-1209	Roller Bracket Assembly	4
16		Inside Glass Panel	1
17		Outside Glass Panel	1
18	ZV-918	Door Guide Vinyl with ZTE-1222	1




When ordering repair parts, please provide the following information:

1. Model Number
2. Part Number
3. Part Description
4. Finish Color

Required Tools:

To install your shower enclosure, you will need the following:

- Level
- #31 Drill Bit
- 3/16" Carbide Drill Bit (for tile walls)
- Phillips Screwdriver
- Silicone
- Hack Saw
- 1/4" Box End Wrench



INSTRUCTIONS:

Note: Apply a bead of silicone (GE 1200) into the open channel of roller bracket before attaching to glass. To assemble roller bracket (15) to glass, tighten screws until surface of roller bracket is depressed 1/32" (28 inch pounds of torque). Allow to cure for 24 hours before hanging sliders.

1. Set wall jambs (1) in place on walls, centering bottom of jambs on rim of tub. Hold plumb and mark walls for screw holes.
2. Remove and drill 3/16" diameter holes in walls (use a carbide tipped drill bit for tiles walls). Insert plastic wall anchors (2) into holes. Silicone where the wall meets the rim of the tub to seal the bottom of jamb. Set jambs in place and secure to the wall with #8 x 1/14" screws (3). Secure bottom bumper (4a) on shower head/inside side with the bottom wall jamb screw.
3. Cut sill (6) to fit opening between jambs. Run a bead of silicone full length to the underside of sill (See Figure 2) and apply silicone to inside of jamb where jamb meets tub. On the inside of jamb, run an 1/4" bead of silicone 1-1/4" up the outside leg of each wall jamb (See Figure 2). Set curb in place, then press firmly to rim of tub. Wipe off any excess silicone before curing. Use tape to hold in place until silicone has set.
4. Cut header (8) 1/32" to 1/16" less than opening width and set in place.
5. To set slider glass in place, hold inside slider inside of tub shower pan, insert rollers up into header and lower into place. The inside slider glass has only one hole for the inside pull handle (10) and will close against the wall jamb on the shower head side. Next, insert lower end of outside slider in front of inside slider by pushing lower ends far enough in to allow clearance on inside edge of tub or pan. Avoid roller brackets to roller bracket contact while lifting panel into place. The outside slider will close against the jamb opposite the shower head.
6. Place center guide (7) to center position on sill (See Figure 2). Make sure the center guide is hooked into the slot position on the sill, then snap center guide to sill.
7. Close panels and adjust to align the vertical edge of panel with jamb. Using a 1/4" box-end wrench, loosen the screws on the rollers, but don't remove completely. When screws are loose, adjust panel by sliding the screw into the slot. NOTE: When screws are loose be sure to support panel so it doesn't fall and break. Adjust the inside slider as low as possible to reduce the gap between bottom of slider and still taking care that the glass does not drag on the track of center guide.
8. To install towel bar (9), place nylon towel bar insert sleeves (13) into holes in the glass (17). Next, hold the tubular towel bar (9) against the hole in the glass with the nylon towel bar/pull washer (12) between the glass and the towel bar.




FIGURE 1




FIGURE 2

Place a nylon towel bar/pull washer on the towel bar/pull screw (11) and secure towel bar in place on both ends. Install the pull the same way the towel bar was installed. Use hole in fastener to tighten (See Figure 3).

9. Center hole in jamb is slotted to allow adjusting of jamb to compensate for bowed glass. After installing hardware, roll both panels into jamb on one side. If edge of glass hits on edge of jamb, loosen center screw and adjust jamb accordingly. Repeat on opposite side.
10. Secure bumpers (4) in place with 6-32 x 1/2" screw SMS (5).
NOTE: Glass panels close into the recessed portion of bumpers. The recess is toward the inside of the tub on the shower head jamb, and toward the outside on the other jamb. From INSIDE of unit, drill #31 holes through header and into wall jamb, 1 1/16" from bottom of header. Secure header to wall jambs with two #6 x 3/8" screws (14).
11. Silicone inside of shower where jambs meet walls and sill meets rim of tub.




FIGURE 3




FIGURE 4

FRAMELESS ENCLOSURES:

Model TETE Euro Tub Enclosure (for 1/4" glass)

Model TESE Euro Shower Enclosure (for 1/4" glass)

Model #	Width	Height	Max. Glass Size
TETE-60	42" to 60"	57-3/8"	30" x 55" w/holes
TETE-66	60" to 66"	57-3/8"	33" x 55" w/holes
TETE-72	66" to 72"	57-3/8"	36" x 55" w/holes
TESE-48	42" to 48"	70-3/8"	24" x 68" w/holes
TESE-60	54" to 60"	70-3/8"	30" x 68" w/holes
TESE-66	60" to 66"	70-3/8"	33" x 68" w/holes
TESE-72	66" to 72"	70-3/8"	36" x 68" w/holes

BREAKDOWN CHART FOR SPECIAL HEIGHT AND WIDTH ETE & ESE UNITS:

QTY.	Part# & Description	How to arrive at measurement
1	ZTE-5201 Header	Unit width minus 1/16"
2	ZTE-1203 Side Jamb	Unit height minus 1-1/8"
1	CHG-TB Towel Bars	Centered on Glass (see instructions below)*
1	CHG KSM	Centered on Glass (see instructions below)*
1	ZTE-1222 Bottom Track	Unit width minus 7/16"

Glass

	1/4" Glass 1/2" holes	
2	Slider Width	Slider width divided by 2
	Height	Unit width minus 2-3/8"

*Center towel bar both top and bottom and side to side.

*Make knob on the inside lite same distance from edge as the towel bar is on the outside lite. Center from top to bottom.