


**PARTS LIST**

ITEM	PART	DESCRIPTION	QTY
1	ZTE-1203	Wall jambs	2
2	ZV-935	Wall Anchors	6
3	#8X 1-1/4"	#8x 1-1/4" Screws	6
4	ZV-924	Door Bumpers	2
4A	ZV-926	Bottom Bumpers	1
5	6-32 X 1/2"	6-32 x 1/2" Screws	2
6	ZTE-1222	Bottom Sill	1
7	ZV-920-4	Center Guide - 3"	1
8	ZTE-6201	Header	1
9	CHG TB	Tubular Towel Bar	1
10	CHG KSM	Tubular Inside Pull	1
11	RP	Recessed Finger Pull	3
12		(RFP) Towel Bar/Knob Fastener	3
13	1" Nylon Wshr	Nylon Rec. Finger Pull Washer	6
14	#6 X 3/8"	#6 x 3/8" Screws	2
15	ZTE-1210D	Roller Bracket Assembly	4
16		Inside Glass Panel w/1 Hole	1
17		Outside Glass Panel w/2 Holes	1
18	ZV-960	Curb Vinyl with ZTE-1222	1




When ordering repair parts, please provide the following information:

1. Model Number
2. Part Number
3. Part Description
4. Finish Color

**Required Tools:**

To install your shower enclosure, you will need the following:


- Level
- #31 Drill Bit
- 3/16" Carbide Drill Bit (for tile walls)
- Phillips Screwdriver
- Silicone
- Hack Saw
- 1/4" Box End Wrench




**INSTRUCTIONS:**

**Note: Apply a bead of silicone (GE 1200) into the open channel of roller bracket before attaching to glass. To assemble roller bracket (15) to glass, tighten screws until surface of roller bracket is depressed 1/32" (28 inch pounds of torque). Allow to cure for 24 hours before hanging sliders.**

1. Set wall jambs (1) in place on walls, centering bottom of jambs on rim of tub. Hold plumb and mark walls for screw holes.
2. Remove and drill 3/16" diameter holes in walls (use a carbide tipped drill bit for tiles walls). Insert plastic wall anchors (2) into holes. Silicone where the wall meets the rim of the tub to seal the bottom of jamb. Set jambs in place and secure to the wall with #8 x 1-1/4" screws (3). Secure bottom bumper (4a) on shower head/inside side with the bottom wall jamb screw.
3. Cut sill (6) to fit opening between jambs. Run a bead of silicone full length to the underside of sill (See Figure 2) and apply silicone to inside of jamb where jamb meets tub. On the inside of jamb, run an 1/4" bead of silicone 1-1/4" up the outside leg of each wall jamb (See Figure 2). Set curb in place, then press firmly to rim of tub. Wipe off any excess silicone before curing. Use tape to hold in place until silicone sets.
4. Cut header (8) 1/32" to 1/16" less than opening width and set in place.
5. To set slider glass in place, hold inside slider inside of tub shower pan, insert rollers up into header and lower into place. The inside slider glass has only one hole for the inside pull handle (10) and will close against the wall jamb on the showerhead side. Next, insert lower end of outside slider in front of inside slider by pushing lower ends far enough in, to allow clearance on inside edge of tub or pan. Avoid roller bracket to roller bracket contact while lifting panel into place. The outside slider will close against the jamb opposite the showerhead.
6. Place center guide (7) to center position on sill (See Figure 2). Make sure the center guide is hooked into the slot position on the sill, then snap center guide to sill.
7. Close panels and adjust to align the vertical edge of panel with jamb. Using a 1/4" box-end wrench, loosen the screws on the rollers, but don't remove completely. When screws are loose, adjust panel by sliding the screw into the slot. NOTE: When screws are loose be sure to support panel so it doesn't fall and break. Adjust the inside slider as low as possible to reduce the gap between bottom of slider and sill taking care that the glass does not drag on the track of center guide.
8. To install towel bar (9), first attach bases of recessed finger pulls (12) to the towel bar (9). Next, hold the towel bar (9) against the hole in the glass with the recessed finger pull washer (13) on the recessed finger pull (11) and secure towel bar (9) in place at both ends. Install the pull (10) the same way the towel bar was installed. Use hole in recessed finger pull to tighten. (See Figure 3)




**FIGURE 1**




**FIGURE 2**

9. Center hole in jamb is slotted to allow adjusting of jamb to compensate for bowed glass. After installing hardware, roll both panels into jamb on one side. If edge of glass hits on edge of jamb, loosen center screw and adjust jamb accordingly. Repeat on opposite side.
10. Secure bumpers (4) in place with 6-32 x 1/2" MS screw (5). NOTE: Glass panels close into the recessed portion of bumpers. The recess is toward the inside of the tub on the shower head jamb, and toward the outside on the other jamb. From inside of unit, drill #31 holes through header and into wall jamps, 1 1/16" from bottom of header. Secure header to wall jamps with two 6x3/8" screws (14).
11. Silicone inside of shower where jamps meet walls and sill meets rim of tub.



**FIGURE 3**



**FIGURE 4**

**FRAMELESS ENCLOSURES:**

Model PRETE Euro Tub Enclosure (for 5/16" glass)

Model PRESE Euro Shower Enclosure (for 5/16" glass)

Model #	Width	Height	Max. Glass Size
PRETE-60	42" to 60"	57-3/4"	30" x 55" w/holes
PRETE-66	60" to 66"	57-3/4"	33" x 55" w/holes
PRETE-72	66" to 72"	57-3/4"	36" x 55" w/holes
PRESE-48	42" to 48"	70-3/4"	24" x 68" w/holes
PRESE-60	54" to 60"	70-3/4"	30" x 68" w/holes
PRESE-66	60" to 66"	70-3/4"	33" x 68" w/holes
PRESE-72	66" to 72"	70-3/4"	36" x 68" w/holes

**BREAKDOWN CHART FOR SPECIAL HEIGHT AND WIDTH PRETE & PRESE UNITS:**

QTY.	Part# & Description	How to arrive at measurement
1	ZTE-6201 Header	Unit width minus 1/16"
2	ZTE-1203 Side Jambs	Unit height minus 1-1/2"
1	CHG-RPTB Towel Bars	Centered on Glass (see instructions below)*
1	CHG-RPKSM Knob	Centered on Glass (see instructions below)*
1	ZTE 1222 Bottom Track	Unit width minus 7/16"

**Glass**

	5/16" Glass 7/8" holes	
2	Slider width height	Slider width divided by 2 Unit height minus 2-3/4"

\*Center towel bar both top to bottom and side to side.

\*Make knob on the inside lite some distance from edge as the towel bar is on the outside lite. Center from top to bottom.